

ELKO EP, s.r.o. Palackého 493

769 01 Holešov, Všetuly Czech Republic Tel.: +420 573 514 211 e-mail: elko@elkoep.com www.elkoep.com



CRM-91HE


Multifunction time relay with external potentiometer

02-187/2016 Rev.: 0

Characteristics

- 10 functions:
- 5 time functions controlled via supply voltage
- 4 time functions controlled via control input
- 1 function of memory (latching) relay
- comfortable function and time setting is done by rotary switches
- remote control by external control unit potentiometer, which can be for example on the doors of switch boar or in panel
- time scale 0.1 s 10 days devided into 10 ranges: (0.1 s - 1 s / 1 s - 10 s / 0.1 min - 1 min / 1 min - 10 min / 0.1 hrs - 1 hrs / 1 hrs - 10 hrs / 0.1 day - 1 day / 1 day - 10 days / only ON / only OFF)
- universal supply voltage AC/DC 12 240 V
- output contact: 1x changeover 16 A
- 1-MODULE, DIN rail mounting


Description



- 1. Supply terminals
- 2. Input for external control time
- 3. Output indication multifunction LED
- 4. Control. input S
- 5. Supply indication
- 6. Rough time setting (0.1s 10 days)
- 7. Function setting
- 8. Output contact

Fine time setting is done by using an external potentiometer.


Symbol





External control potentiometer

Connection



| Type of load | cos φ ≥ 0.95 AC1 | —(M)— AC2 | —(M)— AC3 | =(]⊧ AC5a uncompensated | € E E E E E E E E E E E E E E E E E E E | HAL.230V D S | AC6a | AC7b | AC12 |
|------------------------------------|-------------------------|---------------|--------------|-------------------------------|---|-----------------|-----------|---------------|---------------|
| Mat. contacts AgNi, contact 16A | 250V / 16A | 250V / 5A | 250V / 3A | 230V / 3A (690VA) | х | 800W | х | 250V / 3A | 250V / 10A |
| Type of load | AC13 | _ | 本 | ——— DC1 | —(M)— | M DC5 | DC12 | _ | _ |
| Mat. contacts AgNi, contact 16A | 250V / 6A | 250V / 6A | 250V / 6A | 24V / 16A | 24V / 6A | 24V / 4A | 24V / 16A | 24V / 2A | 24V / 2A |

CRM-91HE

| Number of functions: | 10 |
|---------------------------|---|
| Number of functions. | 10 |
| Supply terminals: | A1 - A2 |
| Voltage range: | AC/DC 12 - 240 V (AC 50 - 60 Hz) |
| Power input: | AC 0.7 - 3 VA / DC 0.5 - 1.7 W |
| Supply voltage tolerance: | -15%; + 10% |
| Supply indication: | green LED |
| Time ranges: | 0.1 s - 10 days |
| Time settings: | rotary switch and external potentiometers |
| Time deviation: | 5 % - mechanical setting |
| Repeat accuracy: | 0.2 % - set value stability |
| Temperature coefficient: | 0.01 % / °C, at = 20 °C |

Output

| Output | |
|------------------------|--|
| Number of contacts: | 1x changeover / SPDT (AgNi / Silver Alloy) |
| Rated current: | 16 A/AC 1 |
| Breaking capacity: | 4000 VA/AC1, 384 W / DC |
| Inrush current: | 30 A / < 3 s |
| Switching voltage: | 250 V AC1 / 24 V DC |
| Output indication: | multifunction red LED |
| Mechanical life: | 3x10 ⁷ |
| Electrical life (AC1): | 0.7x10 ⁵ |

Controlling

| Control. voltage: | AC/DC 12 - 240 V (AC 50 - 60 Hz) |
|--------------------------|----------------------------------|
| Power the control input: | AC 0.025-0.2 VA/DC 0.1-0.7 W |
| Load between S-A2: | Yes |
| Glow tubes connetions: | No |
| Control. terminals: | A1-S |
| Impulse length: | min. 25 ms / max. unlimited |
| Reset time: | max. 150 ms |


Other information

| Other information | |
|------------------------|--|
| Operating temperature: | -20 °C to 55 °C (-4 °F to 131 °F) |
| Storage temperature: | -30 °C to 70 °C (-22 °F to 158 °F) |
| Electrical strength: | 4 kV (supply - output) |
| Operating position: | any |
| Mounting: | DIN rail EN 60715 |
| Protection degree: | IP40 from front panel / IP20 terminals |
| Overvoltage cathegory: | III. |
| Pollution degree: | 2 |
| Max. cable size (mm²): | solid wire max. 1x 2.5 or 2x 1.5 / |
| | with sleeve max. 1x 2.5 (AWG 12) |
| Dimensions: | 90 x 17.6 x 64 mm (3.5″ x 0.7″ x 2.5″) |
| Weight: | 77 g (2.8 oz.) |
| Standards: | EN 61812-1, EN 61010-1 |
| | |

Potentiometer


It is possible to connect the external operating potentiometer up to the distance of maximally 10 meters (32.8 ft.) from relay CRM-91HE, for example in switchboard. The external potentiometer has cover IP65 from the front side and IP20 from the rear side. It is absolutelly necessary to connect potentiometer with the device in correct way. The terminals on the device must be connected to the equally marked terminal on the potentiometer.

| Potentiometer: | 47 kΩ, linear | | |
|------------------------|--|--|--|
| Protection degree: | IP65 from front side / IP20 from back side | | |
| Max. cable size (mm²): | 1.5 with sleeve / without sleeve max. 2.5 (AWG 12) | | |
| Weight: | 15 g (0.5 oz.) | | |



Function

Delay ON after energisation



Cycler beginning with impulse after

Delay OFF after energisation


Cycler beginning with pause after energisation


energisation

Delay OFF after de-energisation, instant make of output

ttttt


Delay OFF responding to make of control contact regardless its length






Delay OFF after break of control contact with instant output


Delay OFF after make and break of control contact






Impulse relay

Pulse generator (puls = 0.5s)





More accurate setting of timing for long periods of time

Example of time setting to 8 hours period:

For rough setting use time scale 1 - 10 s on the potentiomenter.

On the external potentiometer for fine adjustment of time to adjust 8 s, check accuracy (eg. a stopwatch).

On rough time setting, set potentiometer to originally desired scale 1 - 10 hours, leave a fine setting as it is.

Warning

Device is constructed for connection in 1-phase main alternating current and must be installed according to norms valid in the state of application. Connection according to the details in this direction. Installation, connection, setting and servicing should be installed by qualified electrician staff only, who has learnt these instruction and functions of the device. This device contains protection against overvoltage peaks and disturbancies in supply. For correct function of the protection of this device there must be suitable protections of higher degree (A, B, C) installed in front of them. According to standards elimination of disturbancies must be ensured. Before installation the main switch must be in position "OFF" and the device should be de-energized. Don't install the device to sources of excessive electro-magnetic interference. By correct installation ensure ideal air circulation so in case of permanent operation and higher ambient temperature the maximal operating temperature of the device is not exceeded. For installation and setting use screw-driver cca 2 mm. The device is fully-electronic - installation should be carried out according to this fact. Non-problematic function depends also on the way of transportation, storing and handling. In case of any signs of destruction, deformation, non-function or missing part, don't install and claim at your seller. After stop using the product it is possible to demount and recycle.